

Register your New Fleming Product @
<http://www.fleming-agri.co.uk/Products/product-registration.asp>

EU CERTIFICATE OF CONFORMITY

CONFORMING TO EC Machinery Directive 98/37 EC

We

Fleming Agri-Products Ltd
Newbuildings Industrial Estate
Newbuildings
Northern Ireland
BT47 2SX



Declare in sole responsibility, that the products

Type: Mounted Grass Harrow

To which this certificate applies, conforms to the basic safety
and health requirements of the Machinery Directive 98/37 EC,
and the Transposed Harmonised Standard: BS EN 1553 (2000)

Jonathan Lecky
Production Director



Mounted Grass Harrow Operators Manual

**Fleming Agri-Products Ltd
Newbuildings Industrial Estate
Newbuildings
Northern Ireland
BT47 2SX
Tel: (028) 7134 2637
Fax: (028) 7134 4735
Email: info@fleming-agri.co.uk
www.fleming-agri.co.uk**

'Quality, Strength & Personal Service'

This manual is provided to assist you in getting the best results from your machine and ensure that you do so safely. If you have any queries about the use of the machine contact your dealer before use. Please keep this manual for future reference.

1.1 FUNDAMENTAL PRECAUTIONS

On delivery, your dealer gave you an explanation of the operation and maintenance of this Fleming Mounted Grass Harrow. Please read and understand these operating instructions before operating the machine for the first time. It is essential that you observe all safety instructions.

Incorrect use or mishandling of the machine can endanger:

- Life and Limb of the operator, other persons or animals standing within the vicinity of the machine.
- The machine and other material assets of the owner or third persons.
- The performance of the machine.

Anyone who is involved in the commissioning, operation or maintenance of the Mounted Grass Harrow must read and understand the following instructions very carefully and observe them at all times.

NEVER DISTRACT ANYONE WHO IS USING A MACHINE.

1.2 AUTHORISED OPERATORS

Youths under the age of 16 may not operate this implement. The owner of the machine must provide the operator with the operating instructions and make sure they have read and understood them. Only then may the leveller be put into operation.

The owner must ensure that only authorised persons operate/work on this machine. He is responsible for any third persons or animals within the working area of the leveller.

A SAFE DISTANCE OF AT LEAST 5M MUST BE OBSERVED BY ANYONE WITHIN THE VICINITY OF THE Mounted Harrow.

1.3 GENERAL SAFETY AND ACCIDENT PREVENTION REGULATIONS

•Ensure the implement is correctly and securely attached to the operating vehicle. The recommended method of attachment is to use the tractor three point linkage system, always use the correct sized pins.

•**NEVER** attach to a tractor which would be rendered unstable when the implement is operated at its full capacity. Take note of the maximum load permissible on the linkage.

•**NEVER** attempt to move this implement manually.

•Before operation make yourself familiar with all elements and controls of the machine as well as their functions.

•Before operation inspect the area around you. Keep children away. All visitors should be kept away from work area.

•**Under NO Circumstances** should anyone attempt to use the machine as means of personal transport. It is designed as specialist purpose farms implement and is unsuitable for the safe transportation of passengers. **NEVER** allow anyone to travel anywhere between the tractor and the Mounted grass Harrow.

•**NEVER** allow children to play on or around tractors and machinery.

1.4 GENERAL OPERATING INSTRUCTIONS

•This Mounted grass Harrow is a tractor-mounted farm implement. Attempts should not be made to attach the Harrow frame to any other type of vehicle.

• Make sure that the mat is fitted the correct way. With the draw pin to the front.

(see building instructions)

•Ensure the implement is correctly and securely attached to the operating vehicle using the standard 3-point linkage with the lift arm pins provided.

• The fold up wings are for transport mode only. Standing at the back of the machine manually lower the wings.

•Adjust the top link to ensure that the machine is sitting level behind the tractor.

•To operate the machine, using the tractor hydraulics, lower the harrow until the mat is sitting level on the ground and the frame is hovering approximately 150mm above the ground.

• The machine is off-set so that the tines will not track the work area.

• For best results the ideal speed is approximately 5mph.

1.5 MAINTENANCE

•As a rule, disengage the driving system, and stop the engine prior to carrying out maintenance, servicing, cleaning or repair work. **ALWAYS** remove the ignition key.

•Prop the Mounted Grass Harrow with appropriate supports before carrying out any maintenance.

•The manufacturer will not be responsible for any damages or injuries caused by unauthorised repair, alterations or mishandling of the product.

• The generator and battery cables should be disconnected before carrying out any maintenance.

•Maintain product with care. Check periodically for damage that would affect the safe operation of the implement.

•**ALWAYS** ensure all warning stickers are kept clean and in good condition.