


SOILMASTER SPARE PARTS LIST




SOILMASTER TINE CARRIER ASSEMBLY



SEE TABLE NO: 001

TABLE NO: 001 SOILMASTER TINE CARRIER ASSEMBLY			
ITEM NO	DESCRIPTION	SM10	
		CODE	QTY
1	FRONT TINE CARRIER	P001.214	1
2	REAR TINE CARRIER	P001.215	1
3	REAR TINE CARRIER LINKAGE BRACE (WELDED)	P001.216	1
4	CAT1 TOP LINK	ZGPP47	1
5	TINE CARRIER CONNECTOR	P001.217	2
6	RETAINING PIN 65mm LONG	P001.218	8
7	M6x40 ROLL PIN	ZFAS30	14
8	RETAINING PIN 100mm LONG	P001.219	1
9	RETAINING PIN 80mm LONG	P001.220	1
10	STICKER KIT	P001.519	1

SOILMASTER TINE ASSEMBLY




SEE TABLE NO: 002

TABLE NO: 002 SOILMASTER TINE ASSEMBLY

ITEM NO	DESCRIPTION	SM10	
		CODE	QTY
1	TINE COMPLETE WITH POINT	ZGPP40	23
2	TINE POINT	ZGPP43	23
3	TINE BOLT	ZGPP44	23
4	M10 PLAIN NUT	ZFAS05	23
5	M12x50 BOLT ZP	ZFAS15	23
6	TINE CLAMP	ZGPP41	23
7	M12 NYLOCK NUT	ZFAS22	23


SOILMASTER REAR BREAKER BAR ASSEMBLY



SEE TABLE NO: 003

TABLE NO: 003 SOILMASTER REAR BREAKER BAR ASSEMBLY			
ITEM NO	DESCRIPTION	SM10	
		CODE	QTY
1	LEFT HAND BREAKER BAR	P001.221	1
2	RIGHT HAND BREAKER BAR	P001.222	1
3	SM10 RETAINING CHAIN (WELDED ON)	P001.223	2
4	M6x40 ROLL PIN	ZFAS30	4

SOILMASTER CRUMBLER




SEE TABLE NO: 004

TABLE NO: 004 SOILMASTER CRUMBLER

ITEM NO	DESCRIPTION	SM10	
		CODE	QTY
1	CRUMBER COMPLETE	P001.224	1
2	CAT1 TOP LINK	ZGPP47	2
3	RETAINING PIN 65mm LONG	P001.218	2
4	RETAINING PIN 80mm LONG	P001.220	4
5	M6x40 ROLL PIN	ZFAS30	6

SOILMASTER CRUMBLER ASSEMBLY



SEE TABLE NO: 005

TABLE NO: 005 SOILMASTER CRUMBLER ASSEMBLY			
ITEM NO	DESCRIPTION	SM10	
		CODE	QTY
1	SM10 CRUMBLER ROLLER	P001.225	1
2	LEFT HAND CRUMBLER ARM	P001.226	1
3	RIGHT HAND CRUMBLER ARM	P001.227	1
4	CRUMBLER BEARING	ZGPP45	2
5	SM10 SPACER BUSHING	P001.228	2
6	M8x70 ROLL PIN	ZFAS29	2
7	M12x50 BOLT ZP	ZFAS15	8
8	M12 NYLOCK NUT	ZFAS22	8